










תכנות קורא ברקוד אלחוטי HR-1550 (חץ למטה לאחר קריאה)

 99900031	Start Setup
 99900030	Restore to Factory Default
 99904110	It is not Allow to Add End Mark Suffix
 99904102	Set the Custom suffix
 99900000	0
 99900012	A
 99900020	Save Data Parameter
 99904101	Allow to Add Custom Suffix
 99900032	Exit Setup